LINKSMART WITH San-a-Key®

LinkSmart with San-a-Key® ensures your keyboard is always clean

CLEANING INSTRUCTIONS

KSI-1700, 1800, 2000 SX SERIES LINKSMART KEYBOARDS with No-Download, Integrated San-a-Key® Lite



Step 1 — PUSH the red LinkSmart button once to disengage keys. The keys lock, and the Num lock, Caps lock and Scroll lock LED's flash simultaneously, indicating the keyboard is in cleaning mode. You are now able to wipe the surface without risk of entering errant data.



Step 2 — WIPE the keyboard surface with an approved germicidal cloth. Use only KSI-approved wipes. Visit our website to download a list of approved wipes. Cover all areas of the keyboard until thoroughly cleaned. Gloves should be worn when using approved wipes, some of which can be toxic.



Step 3 — PROTECT the keyboard against infection by allowing the surface to remain wet for 30 seconds. Allow one minute of contact time to kill viruses. Allow three-minutes to kill C.difficile spores. Keys are automatically reengaged after completion of the cleaning cycle for resumption of input.

Push, Wipe, Protect — Easy as 1-2-3



(510) 562-5000
14494 Wicks Boulevard
San Leandro, CA 94577
info@ksikeyboards.com
ksikeyboards.com

FOLLOW US